

Structure#43 (PL - 2)

Excavate initial channel connection to high flow channel. Use spoils to fill upstream side of 1 or 2 base logs in logjam.

4-6 ft dia. boulders

